

Anschluss PerfectClima an Wasserversorgung

Wasserschlauch mit dem hierfür vorgesehen Cutter auf die notwendige Länge schneiden



Lösen der Schlauchverbindung

Den Schlauch am Anschluss des Strahlers soweit wie möglich hinein drücken



Wasserschlauch in den Anschluss soweit wie möglich einführen



Den Ring am Anschluss ebenfalls hinein drücken und festhalten



Wasserschlauch ziehen und wieder eindrücken (2 bis 3 mal), um sicheren Sitz herzustellen



Bei gedrückten Ring den Schlauch aus dem Anschluss entfernen



Alle anderen Verbindungen (L-Kupplung, T-Kupplung) funktionieren in gleicher Weise.

Connection of PerfectClime to water supply

Cut the water tube with the cutter to the dedicated lenght



Release of the connection

Push the water tube into the connector as far as possible.



Insert the water tube into the connector as far as possible



Push the ring at the connector piece and keep it in this position.



Push and pull the water tube a couple of times (2 to 3 times), to secure the sealing



While pushing the ring pull out the water tube of the connector.



All other connectors (L-shape, T-shape) work in the same way.